










MAKE: LANDROVER **TYPE:**
MODEL: Series II, IIA, III **YEAR:** 1958 - 1984
DETAIL: L.W.B. Pickup & Station Wagon,
 Santana 109
 S.W.B. Santana 88 **LAND-51**



FRONT	QTY	PART NUMBER
LEAF SPRING Single Stage		
		
	9 Leaves	1 LAND-9L-F RH
	Raised Height (40mm Lift)	1 LAND-9L-F LH
SHACKLE BUSH KIT		
		
S.W.B. Series II, IIA, III L.W.B. Series II, IIA	Kit Contains: 4 x SPF2154 2 x SPF2212	1 PB51-1029K
1973 on, Series III, L.W.B. only	Kit Contains: 4 x SPF2154 2 x SPF2155	1 PB51-1081K
U-BOLT KIT		
		
Series II, IA	Kit Contains: Right Hand Side - 1 x UB51-601-1 1 x UB51-901	1 UB51-901K
	Left Hand Side - 2 x UB51-601-1	1 UB51-601-1K
Series III	Kit Contains: Right Hand Side - 2 x UB51-903	1 UB51-903K
	Left Hand Side - 1 x UB51-902 1 x UB51-903	1 UB51-902K
SHOCK ABSORBER		
		
	Heavy Duty Twin Tube Gas	2 GS51-090
STEERING DAMPER		
		
	Heavy Duty (Big Bore) Complete with Fittings	1 SD51-811

REAR	QTY	PART NUMBER
LEAF SPRING Two Stage		
		
Suits S.W.B.	11 Leaves Raised Height (45mm Lift)	1 LAND-SWB-R RH 1 LAND-SWB-R LH
Suits L.W.B.	8 Leaves Raised Height (45mm Lift)	1 LAND-8L-R RH 1 LAND-8L-R LH
SHACKLE BUSH KIT		
		
	Kit Contains: 6 x SPF2154	1 PB51-1030K
U-BOLT KIT		
		
Series II, IIA	Kit Contains: 2 x UB51-601-1	2 UB51-601-1K
Series III	Kit Contains: 2 x UB51-904	2 UB51-904K
SHOCK ABSORBER		
		
Suits S.W.B., (L.W.B. pre 1958)	Heavy Duty Twin Tube Gas	2 GS21-015C
Suits L.W.B. (1958 on)	Heavy Duty Twin Tube Gas	2 GS59-631